

Übersicht Bahnöffnungen Saxophon

Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Sopranino	C*	1.10 / 15.00										
	C**	1.15 / 15.00										
	D	1.20 / 15.00										
	E	1.25 / 15.00										
	F	1.30 / 15.00										
Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Soprano	C	1.15 / 21.00										
	C*	1.20 / 21.00	170	1.20 / 24.00			C*	1.20 / 20.00				
	C**	1.25 / 21.00	180	1.25 / 24.00			C**	1.25 / 20.00				
	D	1.30 / 21.00	190	1.30 / 24.00			D	1.30 / 20.00				
	E	1.35 / 21.00	200	1.35 / 24.00		E	1.35 / 20.00	E	1.35 / 20.00			
	F	1.45 / 21.00				F	1.45 / 20.00	F	1.45 / 20.00			
	G	1.55 / 21.00				G	1.55 / 20.00					
						H	1.60 / 20.00					
						I	1.65 / 20.00					
						J	1.75 / 20.00					
Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Alto			170	1.40 / 22.00								
			180	1.50 / 22.00								
	C	1.60 / 22.00							C	1.60 / 22.00		
	C*	1.70 / 22.00	190	1.70 / 22.00	C*	1.70 / 22.00		C*	1.70 / 22.00	C*	1.70 / 22.00	
	C**	1.80 / 22.00	200	1.80 / 22.00	C**	1.80 / 22.00		C**	1.80 / 22.00	C**	1.80 / 22.00	
	D	1.90 / 22.00			D	1.90 / 22.00	D	1.90 / 24.00	D	1.90 / 22.00	D	1.90 / 22.00
	E	2.00 / 22.00			E	2.00 / 22.00	E	2.00 / 24.00	E	2.00 / 22.00	E	2.00 / 22.00
	F	2.20 / 22.00			F	2.20 / 22.00	F	2.20 / 23.00	F	2.20 / 22.00	F	2.20 / 22.00
	G	2.40 / 22.00			G	2.40 / 22.00					G	2.40 / 22.00
Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Tenor												
	C	1.70 / 24.00										
	C*	1.80 / 24.00	170	1.80 / 24.00	C*	1.80 / 24.00		C*	1.80 / 24.00	C*	1.80 / 24.00	
	C**	1.90 / 24.00	180	1.90 / 24.00	C**	1.90 / 24.00		C**	1.90 / 24.00	C**	1.90 / 24.00	
	D	2.00 / 24.00	190	2.00 / 24.00	D	2.00 / 24.00		D	2.00 / 24.00	D	2.00 / 24.00	
	E	2.10 / 24.00	200	2.10 / 24.00	E	2.10 / 24.00		E	2.10 / 24.00	E	2.10 / 24.00	
	F	2.30 / 24.00			F	2.30 / 24.00				F	2.30 / 24.00	
	G	2.50 / 24.00			G					G	2.50 / 24.00	
					H		H	2.70 / 24.00				
						I	2.90 / 25.00					
						J	3.10 / 25.00					
Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Baryton	C	1.90 / 27.00										
	C*	2.00 / 27.00	170	2.00 / 27.00								
	C**	2.05 / 27.00	180	2.05 / 27.00								
	D	2.10 / 27.00	190	2.10 / 27.00								
	E	2.20 / 27.00	200	2.20 / 27.00								
	F	2.40 / 27.00										
	G	2.60 / 27.00										
	H	2.80 / 27.00										
Modèle	S 80		S 90		Soloist	Super Session	Metal Classic		Metal Jazz			
Basse	C*	2.10 / 30.00										
	C**	2.15 / 30.00										
	D	2.20 / 30.00										

Übersicht Bahnöffnungen Klarinette

Modèle	Standard		C 85		CP 100	
Mib	C	1.00 / 18.00	105	1.00 / 18.00		
	C*	1.05 / 18.00				
	C**	1.10 / 18.00	115	1.10 / 18.00		
			120	1.15 / 18.00		
Modèle	Standard		C 85		CP 100	
Sib / La						
	C	1.05 / 19.00	105	1.05 / 19.00		
	C*	1.10 / 19.00				
	C**	1.15 / 19.00	115	1.15 / 19.00		
	D	1.20 / 18.00	120	1.20 / 19.00		
	E	1.30 / 18.00			122	1.22 / 27.00
	HS*	1.00 / 18.00				
	HS**	1.20 / 18.00				
Modèle	Standard		C 85		CP 100	
Alto						
	C*	1.70 / 24.00				
	C**	1.75 / 24.00				
Modèle	Standard		C 85		CP 100	
Basse			105	1.70 / 27.00		
	C*	1.80 / 27.00				
	C**	1.85 / 27.00	115	1.85 / 27.00		
	D	1.90 / 27.00	120	1.90 / 27.00		
	E	2.00 / 27.00				
	F	2.10 / 27.00				
	G	2.20 / 27.00				
	H	2.30 / 27.00				
	HS*	1.58 / 27.00				
	HS**	1.90 / 27.00				
Modèle	Standard		C 85		CP 100	
C / Alto						
	C*	1.90 / 30.00				
	C**	1.95 / 30.00				
Modèle	Standard		C 85		CP 100	
C / Basse	C*	1.90 / 30.00				
	C**	1.95 / 30.00				